





Farmall 95



1. Introduction:

A. Proud Owner:


. You are now the proud owner of a Bro-Tek Wheel Spacers. These Wheel Spacers are made for your tractor rear axle. With proper care, the spacers should outlast your original tractor & be ready for your next one. Please read these instructions, before installing the Wheel Spacers. The Wheel Spacers have been designed for easy installation on your tractor. Wheel Spacers are a bolt-on item. Unit will be shipped complete in a box, all hardware included.

B. Feedback:

. We would love any feedback that you could give us (Positive/Negative), to improve our product line. Please email us your comments/pictures too: bro-tek@hotmail.com or you can reach us at www.bro-tek.com

2.

- A. Park on a firm level area.
- B. Stop engine, set brake, remove key and wait for all moving parts to stop before servicing, adjusting or unplugging.
- C. Block up before working beneath unit.











M18 Farmall 95

3. Tools/torque/Parts required:

- **A.** Socket 27mm & 1-1/16"
- B. Torque wrench (capacity rating range 0-210 Lb-Ft).
- C. Floor Jack & Jack stands (proper rating).
- D. Pry-bar, 2x4 lumber 3' or round pipe.
- E. Locktite, Medium Strength Thread locker (Blue)

Assembly Instructions: 4.

- Α. Once you have followed the safety precautions & have removed the Wheel Spacers from its packaging, please take notes of all the parts(see main photo on first page) & follow the assembly instruction.
- Free up work place of all disturbances & clutter. Take your time installing it (This can be easily be done by one person in 20 to 25 minutes).
- C. Before lifting, with the jack, the tractor, break loose the nuts on the rear wheels, this will help out.
- D. If you have the backhoe on, you can save yourself some time & use the stabilizer of the backhoe to lift the rear. For those without a backhoe, jack up & place the jack stand on the tractor.
- △ Jack stands must be stable/secure place on the tractor/ground.
 - E.It's now the time to remove the tire.

Caution if you have loaded tires and haven't taken them off before then beware they can be **VERY heavy**. Make sure that the jack stands are stable before removing the wheel.













M18 Farmall 95

Now is a good time to test fit the spacer to the Axle & then to the wheel rim. The spacer should make full contact to the axle, the rim hole may have to be file a very small amount to clear the spacer lug. It's much easier to sort any problems without having anything bolted down. If everything looks good it time to start the install.

G.To install the spacers, you will need a long bar (3.D) to hold the axle from turning (leave in gear & hand brake on), add (Blue) Thread locker to the bolts. (Get your 1 - 1/16 "socket)

First hand tighten the bolts; Second torque the bolts to half the torque in a crisscross pattern & Finally torque the bolt to their final value of 210 ft. lbs for the rears wheels.

We have found that having a metal shovel and rolling the tire onto it, makes the job of lining up everything must easier. One can slide the tire around, pry & lever the tire into place. below setup is even better...



I. Check clearances around the Wheel, no point of contact should be noticed.







Farmall 95

J. Check everything out for clearances & binding. Recheck nuts & bolts after the first 20 minutes travel & at your regular oil change.

Our recommendations would be to make witness marks after installed, using a paint pens on the back side of the axle lug bolts & also on the studs /lug nut of the wheel side. Make for an easy inspection of the tractor.



5. Congratulations:

You have successfully installed your Bro-Tek Wheel Spacers. I hope this was a pleasant experience & that you would recommend this product to all of your tractor friends. The Wheel Spacers can remain on the tractor, for all the preventative maintenances & every day use.

6. Thank you:

We would like to thank you for supporting us & hope to do future business with you with our new upcoming line of products.

