



www.bro-tek.com

Bro-Tek
-Making tractors parts our business

Metric Lug Bolts 14M



Bro-Tek@hotmail.com



1. **Introduction:**

A. Proud Owner:

. You are now the proud owner of a Bro-Tek Wheel Spacers. These Wheel Spacers are made for your John Deere. It will outlast your original John Deere & be ready for your next one. Please read these instructions, before installing the Wheel Spacers. The Wheel Spacers have been designed for easy installation on your John Deere. Wheel Spacers are a bolt-on item. Unit will be shipped complete in a box, all hardware included. Designed to be very easy to install.

B. Feedback:

. We would love any feedback that you could give us (Positive/Negative), to improve our product line.

Please email us your comments/pictures too:

bro-tek@hotmail.com or you can reach us at www.bro-tek.com

2. **Safety Precautions:**  **Important Safety**

A. Park on a firm level area.

B. Stop engine, set brake, remove key and wait for all moving parts to stop before servicing, adjusting or unplugging.

C. Block up before working beneath unit.



www.bro-tek.com

BRO-TEK
-Making tractors parts our business

Metric Lug Bolts 14M



Bro-Tek@hotmail.com

3. Tools/torque/Parts required:

- A. **Socket** 24mm, 17mm, 3/4" & 11/16"
- B. **Torque wrench** (120 Lb-Ft).
- C. **Floor Jack & Jack stands.**
- D. **Pry-bar or round pipe** (see pic below).
- E. **Loctite**, High Strength Thread locker
- F. **Chainsaw file**


4. Assembly Instructions:

A. Once you have followed the safety precautions & have removed the Wheel Spacers from its packaging, please take notes of all the parts & follow the assembly instruction.


B. Free up work place of all disturbances & clutter. Take your time installing it (This can normally be done by one person in 20 to 35 minutes).

C. Before lifting, with the jack, the JOHN DEERE, break loose the nuts on the rear wheels, this will help out.


D. Jackup & place the jack stand on the JOHN DEERE. (Ref to owners manual)


 Jack stands must be stable/secure place on the JOHN DEERE/ground

E. It's now the time to remove the tire.

 **Caution** if you have loaded tires and haven't taken them off before then beware they can be VERY heavy. Make sure that the jack stands are stable before removing the wheel.

F. The factory bolts treads are 14mmx1.5 tread, We have supplied new Lug bolt 14mmx1.5 use these to install the spacer to the axle

Now is a good time to test fit the spacer to the Axle & then to the wheel rim. The spacer should make full contact to the axle & the nuts/lug bolt has full tread contact, it's much easier to sort any problems without having anything bolted down.

If everything looks good add some Loctite to studs.




www.bro-tek.com


BRO-TEK
-Making tractors parts our business


Metric Lug Bolts 14M



Bro-Tek@hotmail.com

G. To install the spacers, you will need a long bar to hold the axle from turning (see photo) be  careful not to damage the wheel spacers stud tread (a wooden bar or a rag/rubber around the steel bar will help protect the treads, add High Strength Thread locker to the bolts.



Get your socket & make sure to use the supplied Lug bolt that came with the spacers.  the bolts have a tapered end, make sure only tapered bolts are used to install the spacers to the axle.

 Please take the time to make the install/Torque bolt in a 3 steps. First hand tighten the bolts; Second torque the bolts to half the torque in a crisscross/Star pattern & Finally torque the bolt to their final value of 110 ft. lbs for the spacers to the axle.



H. Get your socket & add Loctite to the studs on the spacer. Install the rim/wheel & now use the new nuts from the spacer, making sure they are flip to the proper end. Torque the nuts to 110 ft. lbs for the rim in the same 3 steps as above.

I. Check clearances around the Wheel, no point of contact should be noticed. Make sure to fully turn the steering left/right.

Save these  Instructions/Safety Manual  owner/operator/installer



www.bro-tek.com

Bro-Tek
-Making tractors parts our business

Metric Lug Bolts 14M



Bro-Tek@hotmail.com

J. Check everything out for clearances & binding. Recheck nuts & bolts after the first 2 hours of travel & at your regular oil change.

⚠️ A **low speed** test drive on a bumpy terrain with steering fully rotated should reveal any problem area. Make sure to **correct the problem before any other driving**.

5. **Congratulations:**

You have successfully installed your Bro-Tek Wheel Spacers. I hope this was a pleasant experience & that you would recommend this product to all of your tractor friends. The Wheel Spacers can remain on the JOHN DEERE for all the preventative maintenances & the every day use.

6. **Thank you:**

We would like to thank you for supporting us & hope to do future business with you with our new upcoming line of products.

