



[www.bro-tek.com](http://www.bro-tek.com)



**GF Series Front spacer (M10)**



[Bro-Tek@hotmail.com](mailto:Bro-Tek@hotmail.com)



## 1. Introduction:

### A. Proud Owner:

. You are now the proud owner of a Bro-Tek Wheel Spacers. These Wheel Spacers are made for your Tractor. It will outlast your original Tractor & be ready for your next one. Please read these instructions, before installing the Wheel Spacers. The Wheel Spacers have been designed for easy installation on your Tractor. Wheel Spacers are a bolt-on item. Unit will be shipped complete in a box, all hardware included. Design to be very easy to install.

### B. Feedback:

. We would love any feedback that you could give us (Positive/Negative), to improve our product line.

Please email us your comments/pictures too:

[bro-tek@hotmail.com](mailto:bro-tek@hotmail.com) or you can reach us at [www.bro-tek.com](http://www.bro-tek.com)

## 2. Safety Precautions: **Important Safety**

A. Park on a firm level area.

B. Stop engine, set brake, remove key and wait for all moving parts to stop before servicing, adjusting or unplugging.

C. Block up before working beneath unit.



[www.bro-tek.com](http://www.bro-tek.com)



-Making tractors parts our business

**GF Series Front spacer (M10)**



[Bro-Tek@hotmail.com](mailto:Bro-Tek@hotmail.com)

3. Tools/torque/Parts required:

- A. **Socket** 24mm, 17mm, 3/4", 5/8" & 11/16"
- B. **Torque wrench** (capacity rating range 0-130 Lb-Ft).
- C. **Floor Jack & Jack stands.**
- D. **Pry-bar or round pipe or even better a piece of 2x4 lumber.**
- E. **Loctite, Medium Strength Thread locker (Blue)**

4. Assembly Instructions:

A. Once you have followed the safety precautions & have removed the Wheel Spacers from its packaging, please take notes of all the parts & follow the assembly instruction.

B. Free up work place of all disturbances & clutter. Take your time installing it (This can normally be done by one person in 20 to 35 minutes).

C. Before lifting, with the jack, the TRACTOR, break lose the nuts on the wheels, this will help out.

D. Jack up & place the jack stand on the. (Ref to owner's manual)  
Jack stands must be stable/secure place on the TRACTOR/ground

E. It's now the time to remove the tire.

**⚠ Caution** if you have loaded tires and haven't taken them off before then beware, they can be VERY heavy. Make sure that the jack stands are stable before removing the wheel.

F. The factory studs to remain remove and save the nuts. These nuts, you will have to reuse on the wheel installation at the very end. We supplied new silver lug nuts, which has the proper taper cone to match the inside of the spacer.

Now is a good time to test fit the spacer to the Axle & then to the wheel rim. The spacer should make full contact to the axle; it's much easier to sort any problems without having anything bolted down.

If everything looks good add Loctite 5 lug new silver lug nuts ⚠,

G. To install the spacers, you will need a long bar to hold the axle from turning, we prefer a 2x4 lumber on sideways.



[www.bro-tek.com](http://www.bro-tek.com)





-Making tractors parts our business


**GF Series Front spacer (M10)**



[Bro-Tek@hotmail.com](mailto:Bro-Tek@hotmail.com)

---

 careful not to damage the wheel spacers stud tread (a Wooden bar or a rag/rubber around the steel bar will help protect the treads. Get your socket & make sure to use the new silver Lug nut. Not  factory nut. The new nuts have a tapered end, make sure only used to install the spacers to the axle.

 Please take the time to make the install/Torque bolt in 3 steps. First hand tightens the bolts; Second torque the bolts to half the torque in a crisscross/Star pattern & finally torque the bolt to their final value of 55 ft. lbs for the spacers to the axle.




H. Reinstall the wheel & install the & torque the original OEM nuts to 60 ft. lbs for the wheels.

We have found that having a metal shovel and rolling the tire onto it, makes the job of lining up everything must easier. One can slide the tire around, pry & lever the tire into place.

I. Check clearances around the Wheel, no point of contact should be noticed.

J. Check everything out for clearances & binding. Recheck nuts & bolts after the first 2 hours of travel & at your regular oil change.

 A **low-speed** test drive on a bumpy terrain with steering fully rotated should reveal any problem area. Make sure to **correct the problem before any other driving.**



[www.bro-tek.com](http://www.bro-tek.com)



-Making tractors parts our business

**GF Series Front spacer (M10)**



[Bro-Tek@hotmail.com](mailto:Bro-Tek@hotmail.com)

---

Our recommendations would be to make witness marks after installed, using a paint pen on the back side of the axle lug bolts & also on the studs /lug nut of the wheel side. Make for an easy inspection of the tractor.



**5. Congratulations:**

You have successfully installed your Bro-Tek Wheel Spacers. I hope this was a pleasant experience & that you would recommend this product to all of your tractor friends. The Wheel Spacers can remain on the TRACTOR for all the preventative maintenances & the every day use.

**6. Thank you:**

We would like to thank you for supporting us & hope to do future business with you with our new upcoming line of products.